

QUICK GUIDE



Press the button: blue light indicates the robot is powered on

Press the button again: red light indicates the robot is powered off



ROBOT IS POWERED ON




ROBOT IS POWERED OFF



Place the robot into the pool with the bottom towards the wall

Submerge the robot into water for 20 seconds to empty trapped air






The robot will move to the pool edge when it finishes working

Use the provided hook to lift it out of the pool




QUICK GUIDE



Take out the filter basket from the top cover and rinse it with water

Make sure the filter basket is clean after each use



Make sure the charger and charging port are clean and dry before charging

It is recommended to store fully charged if not going to be used for longer than 6 months

Use original and authorized charger only

Please charge at a maximum interval of no more than 6 months